

District I  
1625 N. French Dr., Hobbs, NM 87240  
District II  
811 South First, Artesia, NM 87210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

LL API NO.  
30-025-~~05300~~ **05303**  
5. Indicate Type of Lease  
STATE ☐ FEE ☒  
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)  
1. Type of Well:  
Oil Well ☒ Gas Well ☐ Other ☐  
2. Name of Operator  
Fasken Oil and Ranch, Ltd.  
3. Address of Operator  
303 W. Wall Ave., Suite 1800, Midland, TX 79701-5116  
4. Well Location  
Unit Letter E : 1980 feet from the North line and 787 feet from the West line  
Section 11 Township 15S Range 37E NMPM County Lea  
10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3803' GL

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:  
PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:  
REMEDIAL WORK ☒ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1. RUPU NDWH and NU BOP.
2. RIW with 2-3/8" Tubing to top of CIBP at 9120' and spot 25 sks Class H cmt on top. POW to 8800' and spot 27 bbls mud laden brine.
3. POW to +/-7640 spot 25 sks Class H cement (DV plug). POW to 7300' and spot 70 bbls mud laden brine.
4. RIW with packer and establish rate between leaks at 3398-3446' and 4467'-4531' with packer at +/- 4300'. POW with packer and RIW with 5-1/2" CICR on tubing to 4300'. Set retainer and pump 80 sks Class C cmt thru retainer.
5. Sting out reverse out cement and WOC 4 hours. Pressure test top leak to 500 psi for 10 minutes. Spot 50 sacks Class C cmt on top of retainer.
6. POW and spot 25 sacks Class C cmt +/-3050' and POW to 2700' and spot mud laden brine.
7. POW and spot 25 sacks Class C cmt +/-2185' (salt plug top of salt 2135'). POW to 1900' and spot mud laden brine.
8. POW and spot 25 sacks Class C cmt +/-375'. WOC and Tag plug.
9. Spot surface plug with 10 sacks Class C cmt diog out and cut off 8-5/8" and 5-1/2" casing 3' below ground level and weld on steel plate with 1" ball valve and install 5-1/2" O.D. X 10' dry hole marker.

The work will be done on or about 8/20/00.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Calvin Gene Turner TITLE Production Superintendent DATE 7-26-01

Type or print name Calvin Gene Turner

Telephone No. (915) 687-1777

(This space for State use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ Orig. Signed by Paul Kautz DATE \_\_\_\_\_  
Conditions of approval, if any: Geologist

RECEIVED  
JUL 20 2014  
Hobbs  
000