

1 OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Atlantic Richfield Company</b>		8. Farm or Lease Name <b>Graham</b>
3. Address of Operator <b>P. O. Box 1978, Roswell, New Mexico 88201</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>O</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>15</b> TOWNSHIP <b>15-S</b> RANGE <b>38-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Medicine Rock-Dev.</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3740' ground</b>		12. County <b>Lea</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Production from this well has decreased to approximately 20 BOPD plus 85% water. Due to the high cost of deep hydraulic pumping and disposal of salt water, the well is no longer economical. We propose to P & A as follows:

1. Place latch type DR plug in 415-D packer @ 12725' & cap w/15 sx cement.
2. Shoot off and recover 5-1/2" csg as deep as possible (top of cement @ 11200').
3. Spot these cement plugs:  
35 sx in & out of 5-1/2" casing stub.  
35 sx from 8250-8150' (top of Abo @ 8192')  
25 sx from 6450-6375' (top of Glorieta @ 6412')  
35 sx from 4975-4875' (9-5/8" shoe @ 4926')  
10 sx in top of well.

13-3/8" & 9-5/8" csg strings will remain intact. Dry hole marker will be installed & location cleared & levelled.

18. I hereby certify that the information above is true and correct to the best of my knowledge and belief.

SIGNED O. D. Bretches TITLE Dist. Drlg. Supervisor DATE 2/26/69

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: