

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> <u>Water Injection</u>	7. UNIT AGREEMENT NAME <u>MCA</u>
2. NAME OF OPERATOR <u>Continental Oil Co.</u>	8. FARM OR LEASE NAME <u>MCA Unit #1</u>
3. ADDRESS OF OPERATOR <u>Box 460 Hobbs N. Mex</u>	9. WELL NO. <u>22</u>
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>660' FNL and 660' FWL of Sec 20</u>	10. FIELD AND POOL, OR WILDCAT <u>Maly G-SA Repress</u>
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>3964' df</u>
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>Sec 20, T-17S R-32E</u>
	12. COUNTY OR PARISH <u>Lea</u>
	13. STATE <u>N. Mexico</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☒FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to shut off water in this well by the following procedures: Set open hole bridge plug at 3635'-3650'. Spot sand on top of BP to 3600'-3605'. Set cement retainer at 3475' and squeeze open hole w/ 85 socks class C cement. Drill out retainer and plug to $\pm 5'$ below casing shoe and pressure test to 700 psi.

18. I hereby certify that the foregoing is true and correct

SIGNED

Robert Gault III

TITLE

Admin. Supervisor

DATE

12-29-72

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

JAN - 1973

J L GORDON
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

USGS-5 MCA-3 File