

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Polaris Production Corp.</b>	8. Firm or Lease Name <b>Priest</b>
3. Address of Operator <b>P. O. Box 1749, Midland, Texas 79701</b>	9. Well No. <b>3</b>
4. Location of Well UNIT LETTER <b>C</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1650</b> FEET FROM THE <b>West</b> LINE, SECTION <b>1</b> TOWNSHIP <b>15 S</b> RANGE <b>37 E</b> N.M.P.M. 10. Field and Pool, or Wildcat <b>Denton Mississippian</b>	11. County <b>Lea</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3808' DF</b>	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <u>Perforate the Mississippian</u> <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed operations to re-complete in the Mississippian formation.

1. Unseat pkr., lay down 2 7/8" tbg., bottom hole assy. and seal assy.
2. Pump 145 bbl Devonian fm. wtr. in csg.
3. Run gauge ring and junk basket to 12,200'
4. Set CIBP at 12,200' and dump 3 sx of cmt. on top.
5. Log section 12,100-11,500' w/GR-N
6. Perforate section 11,680-11,690 w/4 JSPF
7. Go in hole w/pkr. and tbg.
8. Fill hole w/fm. wtr.
9. Wash by perms w/1000 gal. NE-FE 15%
10. Set pkr. and acidize perms w/1000 gals. NE-FE 15%
11. Swab tbg. and test well
12. Pull tbg. and pkr.
13. Place well on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED William H. Spivey TITLE Engineer DATE July 7, 1975

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: