

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANCTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>		7. Unit Agreement Name <b>Maljanar (Grayburg)</b>
2. Name of Operator <b>Chevron Oil Company</b>		8. Farm or Lease Name <b>Maljanar Unit</b>
3. Address of Operator <b>P. O. Box 1660, Midland, Texas 79701</b>		9. Well No. <b>46</b>
4. Location of Well UNIT LETTER <b>M</b> , <b>1300</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>Last</b> LINE, SECTION <b>9</b> TOWNSHIP <b>17-S</b> RANGE <b>32-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Maljanar (Grayburg-San Andres)</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>GR 4115</b>		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to commence third quarter 1975. State office will be notified prior to commencing actual plugging operations.

1. Dig pit and cellar.

2. Run in hole with tubing open ended, to 3800', displace hole with 9.5 ppg mud laden fluid. Spot 25 sac cement. Pull tubing to 2400' and spot 30 sac cement. Pull tubing to 2000' and spot 35 sac cement. Pull out of hole with tubing.

3. Perforate 4 1/2" casing at 355'. Establish circulation, pump sufficient cement to circulate to surface via annulus leaving 4 1/2" casing full.

4. Cut off casing 2-3' below ground level, set 4' marker. Back fill pits and cellar. Clean up location as per federal or state requirements.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. T. Kryzulk E. T. Kryzulk

TITLE Division Drilling Superintendent Date July 31, 1975

APPROVED BY \_\_\_\_\_

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: