

8. (cont'd). Same as step no. 5.
9. WOC 24 hrs. Drill out and test to 500 psi.
10. GIH w/2-3/8" tbg. and retrievable pkr. and set at 10,300 \pm after cleaning out to T.D.
Acidize as follows: 3 - 4 BPM
 - A. Pump 2000 gallons 15% HCL NE,
 - B. Drop 200# diverting plug consisting of 120# Benzoic Acid flakes and 80# Paraformaldehyde mixed in 200 gallons of WF 40 gelled water.
 - C. Repeat Steps A and B four times
 - D. Flush to perforations with water.
11. Obtain step rate test.
12. POH and lay down 2-3/8" work string
13. Pick up internally plastic coated tubing with Baker Model "R" Packer and set @ 10,300'.
14. Load 4-1/2" x 2-3/8" casing annulus with inhibited water (Cronox) and install pressure gauge.
15. Hook up well head.
16. Place well on SWD service.