

COPIES RECEIVED		
CONTRIBUTION		
FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
 Supersedes Old  
 C-102 and C-103  
 Effective 1-1-65

5a. Indicate Type of Lease  
 State  Fee   
 5. State Oil & Gas Lease No.  
**K-4676**

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL  GAS WELL  OTHER   
 2. Name of Operator  
**Gulf Oil Corporation**  
 3. Address of Operator  
**Box 670, Hobbs, New Mexico 88240**  
 4. Location of Well  
 UNIT LETTER **M**, **660** FEET FROM THE **South** LINE AND **660** FEET FROM THE **West** LINE, SECTION **34** TOWNSHIP **16-S** RANGE **34-E** NMPM.  
 7. Unit Agreement Name  
 8. Farm or Lease Name  
**Lea PS State**  
 9. Well No.  
**1**  
 10. Field and Pool, or Wildcat  
**No, Vac Lower Wo.**  
 11. Elevation (Show whether DF, RT, GR, etc.)  
**4078' GL**  
 12. County  
**Lea**

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Plug and Abandon</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10,875' TD.

Pull producing equipment. Set CI BP at approximately 10,000'. Load hole with water. Spot 35' cement on top of BP. Set CI BP at approximately 8475' and load hole with abandonment mud. Spot 35' cement plug on top of BP. Cut and recover 5-1/2" casing from approximately 5750'. Spot 100' cement plug across 5-1/2" casing stub; 100' cement plug from 4650' to 4550', across top of San Andres; 100' cement plug from 4140' to 4040', across 8-5/8" shoe at 4090'. Cut and recover 8-5/8" casing from approximately 2300'. Spot 100' cement plug across 8-5/8" stub; 100' cement plug across top of salt at 1770'; 100' cement plug from 428' to 328', across 13-3/8" shoe at 378' and 10 sack cement plug at surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED K. J. Bruneale TITLE Area Engineer DATE March 18, 1974

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

MAR 19 1974