

COPIES RECEIVED	
TRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-4676	
7. Unit Agreement Name	
8. Farm or Lease Name	
Lea PS State	
9. Well No.	
2	
10. Field and Pool, or Willcat	
No. Vac Lower Wo.	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
Gulf Oil Corporation
3. Address of Operator
Box 670, Hobbs, New Mexico 88240
4. Location of Well
UNIT LETTER K, 1875 FEET FROM THE South LINE AND 2085 FEET FROM THE West LINE, SECTION 34 TOWNSHIP 16-S RANGE 34-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
4078' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>
OTHER Plug and Abandon <input checked="" type="checkbox"/>			

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10,835' TD.

Pull producing equipment. Set CI BP at 10,600'. Load hole with abandonment mud and cap BP with 35' cement plug. Cut and recover 5-1/2" casing from approximately 7000'. Spot 100' cement plug across 5-1/2" casing stub; 100' cement plug from 6150' to 6050', across top of Glorietta; 100' cement plug from 4670' to 4570', across top of San Andres; 100' cement plug from 4139' to 4039', across 8-5/8" shoe at 4089'. Cut and recover 8-5/8" casing from approximately 2400'. Spot 100' cement plug across 8-5/8" stub; 100' cement plug from 1570' to 1850', across top of salt; 100' cement plug from 456' to 356', across 13-3/8" shoe at 406' and 10 sack cement plug at surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>K. J. Brazzale</u>	TITLE <u>Area Engineer</u>	DATE <u>March 18, 1974</u>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		