

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-3361-3	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Holliday Drilling Company		8. Farm or Lease Name Montieth State "B"
3. Address of Operator 206 First Savings Building, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER I , 1880 FEET FROM THE South LINE AND 990 FEET FROM THE East LINE, SECTION 19 TOWNSHIP 16S RANGE 37E NMPM.		10. Field and Pool, or Wildcat Northeast Lovington (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 3844 DF		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull tubing out of well. Set bridge plug at 11,200' and dump 35 foot plug on top of it. Cut off and recover 5 1/2" casing at lowest depth possible. (Temperature survey-9580'). Set 100 cement plugs as follows:

1. 100' in and out of 5 1/2" stub.
2. 100' at top of Abo at 8340'
3. 100' at top of Glorietta
4. 100' in and out of shoe of 8 5/8" casing at 4355'

Cut off and recover 8 5/8" casing at lowest depth possible. Set plugs as follows:

1. 100' in and out of stub of 8 5/8"
2. 100' at base of salt at 4050'
3. 100' at top of salt at 2242'
4. 100' in and out of shoe of 12 3/4" surface casing at 352'
5. 10 sx plug at surface (with marker)

9.5# mud between plugs.

**Verbal Approval by John Runyon
9:00 AM 7-25-73**

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Richard L. Robison</u>	TITLE Partner	DATE 7-25-73
Orig. Signed by <u>Joe D. Ramsey</u> Dist. I, Supv.		
APPROVED BY _____	TITLE _____	DATE <u>7-27-73</u>
CONDITIONS OF APPROVAL, IF ANY:		

