

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5744	
7. Unit Agreement Name Not Required	
8. Farm or Lease Name Garrett State	
9. Well No. 1	
10. Field and Pool, or Wildcat Undesignated	
12. County Lee	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER-

2. Name of Operator
Anderson Oil and Gas Company, Inc.

3. Address of Operator
250 Mid-America Building, Midland, Texas 79701

4. Location of Well
UNIT LETTER **M**, **2080** FEET FROM THE **West** LINE AND **560** FEET FROM THE **South** LINE, SECTION **31** TOWNSHIP **16-S** RANGE **38-E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
GL 3734

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move In Casing Pullers, Inc., clean out around surface casing and remove well location marker.
2. Weld onto 8 5/8" intermediate casing and pull to determine free point.
3. Cut off and pull 8 5/8" intermediate casing (estimate 1200').
4. Pickup 2 3/8" tubing and spot 100' cement plug from 1250' to 1150'.
5. Pull 2 3/8" tubing to 446' and spot 100' cement plug from 446' to 346'.
6. Pull tubing and spot 10sk plug at the surface and install well location marker.

* Spot 9.55 mud between all plugs and notify Conservation Commission.24 hours prior to P & A.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE **Engineer** DATE **1-21-74**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: