	tate of New Mex and Natural Res	ico ources Department		Form C-103 Revised 1-1-89
	ERVATION	N DIVISION	WELL API NO.	
D. Box 1980, Hobbs, NM 88240	P.O. Box 2088	3		5-24559
STRICT II Santa Fe, D. Drawer DD, Artesia, NM 88210	New Mexico 8	7504-2088	5. Indicate Type of Le	STATE FEE X
STRICT III 00 Rio Brazos Rd., Aztec, NM 87410			6. State Oil & Gas Le	ase No.
SUNDRY NOTICES AND REPO	BTS ON WELL	S		
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL DIFFERENT RESERVOIR. USE "APPLIC (FORM C-101) FOR SUCH PR	OR TO DEEPEN C	OR PLUG BACK TO A	7. Lease Name or Uni	it Agreement Name
Type of Well: OL OAS WELL WELL X	OTHER		R. L.	Burns ATL
Name of Operator			8. Well No.	1
YATES PETROLEUM CORPORATION	- ,		9. Pool name or Wild	
Address of Operator 105 South 4th St., Artesia, NM 88	210		1	ssissippian
Well Location				·
Unit Letter : Feet From The	South		Feet From Th	ie Line
n. La ana an a	16S Ran	ige 35E	NMPM Lea	a County
Section 11 Township	tion (Show whether L	OF, RKB, RT, GR, etc.)	P	
	3971'			
Check Appropriate Box	x to Indicate N	lature of Notice, R	Report, or Other D	Data
NOTICE OF INTENTION TO:		SUE	BSEQUENT RE	PORT OF:
				PORT OF:
NOTICE OF INTENTION TO:		SUE REMEDIAL WORK		
		SUE REMEDIAL WORK COMMENCE DRILLIN		PORT OF:
NOTICE OF INTENTION TO:		SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C		
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA		SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C		
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AE MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER:	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C	G OPNS. C PL	PORT OF: _TERING CASING [_UG AND ABANDONMENT [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AB MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER:	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: <u>Spud</u> d give pertinent dates, incl	G OPNS. AL	PORT OF: _TERING CASING [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AN MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1–19–2000 – Dig out cellar and re	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: <u>Spud</u> d give pertinent dates, incl nole marker. (GOPNS. Constrained date of st Cut and dressed	PORT OF: _TERING CASING LUG AND ABANDONMENT warring any proposed d off 13-3/8"
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AN MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER:	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: <u>Spud</u> d give pertinent dates, incl nole marker. (AL GOPNS. AL COPNS.	PORT OF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1–19–2000 – Dig out cellar and rec casing. 1–20–2000 – Welded on 13–3/8" X I Scraped and levelled location.	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. C nead. Installe Moved in re-	GOPNS. AL GOPNS. PL EMENT JOB On re-entry Wing estimated date of sta Cut and dressed ed new cellar -entry equipment	PORTOF: _TERING CASING [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER:	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re-	GOPNS. ALL GOPNS. CONS.	PORTOF: _TERING CASING [_UG AND ABANDONMENT [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AN MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud of d give pertinent dates, incl nole marker. (nead. Installe Moved in re- unit. Nippled pudded in at 11 lars and TIH.	SEQUENT REI	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X 1 Scraped and levelled location. So and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. (head. Installe Moved in re- unit. Nippled pudded in at 11 11ars and TIH. plastic and me	SEQUENT RE	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X 1 Scraped and levelled location. So and 12" 3000 BOP. 1-21-2000 - Moved in and rigged ut tooth bit and drill collars with of cement and fell out. Picked ut 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on	BANDON	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. (head. Installe Moved in re- unit. Nippled pudded in at 11 11ars and TIH. plastic and me	SEQUENT RE	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2 Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in.	BANDON DANS DANS DANS DANS DANS DANS DANS DAN	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and market Made 2 runs	GOPNS. GOPNS. GOPNS. Con re-entry Maing estimated date of standing estimated and dressed as a construct as	PORTOF: _TERING CASING [_UG AND ABANDONMENT [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2 Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in.	BANDON DANS DANS DANS DANS DANS DANS DANS DAN	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and market Made 2 runs	GOPNS. GOPNS. GOPNS. Con re-entry Maing estimated date of standing estimated and dressed as a construct as	PORTOF: _TERING CASING [_UG AND ABANDONMENT [
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with	BANDON DANS DANS DANS DANS DANS DANS DANS DAN	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril	SEQUENT REL GOPNS. AL GOPNS. PL EMENT JOB On re-entry wing estimated date of st Cut and dressed ed new cellar -entry equipment up BOP. TIH 1:00 AM 1-20-2 Tagged up at etal shavings - got fine met ated & TOOH. 1ed cement to	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. So and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'.	BANDON NS periment details, and emoved dry h 13-5/8" 3K h Set anchors up pulling to swivel. Sy up drill con- tting wood, drillpipe. net on dril bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud co d give pertinent dates, incl nole marker. Con head. Installed Moved in re- unit. Nippled pudded in at 12 llars and TIH. plastic and mark Made 2 runs lpipe. Circul llars and dril	SEQUENT RE AL GOPNS. AL COPNS.	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AS MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with	BANDON NS <i>pertinent details, and</i> emoved dry h 13-5/8" 3K h Set anchors. up pulling to swivel. Sp up drill conditing wood, drillpipe. net on drill bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril	SEQUENT RE AL GOPNS. AL COPNS.	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. So and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'.	BANDON NS <i>pertinent details, and</i> emoved dry h 13-5/8" 3K h Set anchors. up pulling to swivel. Sp up drill conditing wood, drillpipe. net on drill bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud co d give pertinent dates, incl nole marker. Con head. Installed Moved in re- unit. Nippled pudded in at 12 llars and TIH. plastic and mark Made 2 runs lpipe. Circul llars and dril	SEQUENT RE AL GOPNS. AL COPNS.	PORTOF: _TERING CASING _UG AND ABANDONMENT _ arring any proposed d off 13-3/8" and backfilled. nt. Set on spool with 12-1/4" mill 000. Drilled 15' 200'. Drilled back. POOH with al cuttings back. Had a 5-1/2" OD 335'. Ran next PAGE: DATE_JUNE 16, 2000
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2 Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'.	BANDON NS <i>pertinent details, and</i> emoved dry h 13-5/8" 3K h Set anchors. up pulling to swivel. Sp up drill conditing wood, drillpipe. net on drill bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. (head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril beier. CONT Derations	SEQUENT RE	PORTOF: _TERING CASING
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'. I hereby certify the the information above is the ard complete to the best SKONATURE Rusty Klein	BANDON NS <i>pertinent details, and</i> emoved dry h 13-5/8" 3K h Set anchors. up pulling to swivel. Sp up drill conditing wood, drillpipe. net on drill bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud C d give pertinent dates, incl nole marker. C head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril	SEQUENT RE	PORTOF: _TERING CASING _UG AND ABANDONMENT _ arting any proposed d off 13-3/8" and backfilled. nt. Set on spool with 12-1/4" mill 000. Drilled 15' 200'. Drilled back. POOH with al cuttings back. Had a 5-1/2" OD 335'. Ran next PAGE: _ DATE June 16, 2000 TELEPHONE NO. 505/748-
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'. I hereby certify that the information above is the and complete to the beat SKONATURE WITH WITH INCOMPLETED AND AND AND AND AND AND AND AND AND AN	BANDON NS <i>pertinent details, and</i> emoved dry h 13-5/8" 3K h Set anchors. up pulling to swivel. Sp up drill conditing wood, drillpipe. net on drill bit and co	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. (head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril beier. CONT Derations	SEQUENT RE	PORTOF: _TERING CASING _UG AND ABANDONMENT _ arring any proposed d off 13-3/8" and backfilled. nt. Set on spool with 12-1/4" mill 000. Drilled 15' 200'. Drilled back. POOH with al cuttings back. Had a 5-1/2" OD 335'. Ran next PAGE: DATE_JUNE 16, 2000
NOTICE OF INTENTION TO: RFORM REMEDIAL WORK PLUG AND AR MPORARILY ABANDON CHANGE PLA LL OR ALTER CASING HER: 2. Describe Proposed or Completed Operations (Clearly state all work) SEE RULE 1103. 1-19-2000 - Dig out cellar and rec casing. 1-20-2000 - Welded on 13-3/8" X I Scraped and levelled location. S and 12" 3000 BOP. 1-21-2000 - Moved in and rigged u tooth bit and drill collars with of cement and fell out. Picked u 10' of cement and got rough - get bit. TIH with 11-1/4" magnet on Shut well in. 1-22-2000 - TIH with 11-3/4" magn X 1/2" plate of steel. TIH with joint - wash and ream to 1412'. I hereby certify the the information above is the ard complete to the best SKONATURE Rusty Klein	BANDON NS pertiment details, and emoved dry h 13-5/8" 3K h Set anchors, up pulling u swivel. Sp up drill co tting wood, drillpipe. net on dril bit and co st of my knowledge and	SUE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Spud c d give pertinent dates, incl nole marker. (head. Installe Moved in re- unit. Nippled pudded in at 1 lars and TIH. plastic and may Made 2 runs lpipe. Circul llars and dril beier. CONT Derations	SEQUENT RE	PORTOF: _TERING CASING _UG AND ABANDONMENT _ arting any proposed d off 13-3/8" and backfilled. nt. Set on spool with 12-1/4" mill 000. Drilled 15' 200'. Drilled back. POOH with al cuttings back. Had a 5-1/2" OD 335'. Ran next PAGE: _ DATE June 16, 2000 TELEPHONE NO. 505/748-



•

YATES PETROLEUM CORPORATION R. L. Burns ATL #1 Section 11-T16S-R35E Lea County, New Mexico

SUNDRY NOTICE CONTINUED:

1-23-2000 - Washed and reamed. Tagged 8-5/8" stub at 1438'. TOOH. TIH with 7-7/8" bit and drill collars and tagged stub. Felt like it rolled in and drilled down 43'. Have indications of being on outside of pipe. TOOH - outside of bit shanks scarred up, outside teeth on cones not hurt. TIH with 11-3/4" OD skirted dress off mill and tagged top at 1438'. NOTE: Think pipe is slivered. Milled 3 hours and made 1'. TOOH. Cut lipe guide worn off like it has been cutting formation. TIH with 10-3/4" skirted dress off mill with flat rough bottom (rough OD, smooth ID). 1-24-2000 - TIH and tagged top of stub and worked over 10-3/4" dress off mill. Started milling. Milled 5-1/2'. TOOH. Rigged up casing crew. Ran 35 joints of 8-5/8" 32# ST&C (1541.72') of casing set at 1516'. Slip joint set at 1516'. NOTE: Tied into existing 8-5/8" casing. Cemented with 545 sacks "C" Neat (yield 1.32, weight 14.8). Pressured up to 200 psi & set slips. Cut off and nippled down BOP. Nippled up 13-5/8" 3K X 11" 5K head. Nippled up BOP. TIH with 7-7/8" bit & drill collars and tagged up at 1442'. Rigged up swivel and drilling on junk. Drilling at 1463' at report time. 1-25-2000 - Worked bit thru spot at 1482'. Drilled down t 1495' and fell out of fill. Tagged up at 1562'. Drilled down to 1585' - rough - quit making hole. TOOH. Rigged up rotary wireline and ran 3-arm caliper log. Shows 8-5/8" parted from 1488-1492' and 1476-1478'. TIH with 7-5/8" flat bottom mill with smooth OD, mesh ID and bottom. Worked thru parts and cut over junk to 1630', cutting cement, try to core. TOOH - no core. TIH with new 7-7/8" bit. 1-26-2000 - TIH with new 7-7/8" bit, jars & drill collars. Worked thru part at 1482'. Started drilling cement at 1630'. Drilled on junk, getting cement back. Drilled to 1724' & fell out of cement. TIH. Washed down to 4544'. Displaced dehydrated mud. Drilled 2' of cement. Circulate clean. TOOH. Rigged up Rotary Wireline & ran 3-arm caliper log to see if casing was shot again below 1500'. 1-27-2000 - Ran 3 arm caliper log from 4500-1400' - casing intact below 1500'. Rigged down wireline. Nippled down BOP stack & casing head. Nippled up BOP stack. TIH with 8-5/8" spear and stabbled into 8-5/8" casing. Pulled up and set on slips. Rigged up casing crew and laid down 34 joints of 8-5/8" 32# casing with slip joint. Had galled pins and boxes. TIH with casing spear with 8.13 grapple and latched onto 8-5/8" casing. Jarred 2 hours and came loose. TOOH. Had 40' joint of casing on spear with coupling on bottom, just above coupling, casing had been collapsed. Bit had cut a hole in flat side 3', 10' bad spot. TIH with 12-1/4" bit to open hole above stub. Washed down and tagged stub (tagged up at 1483'). TOOH. TIH with 7-1/4'' inside cutter and tagged top. Went inside 30' and made cut. 1-28-2000 - TIH with inside cutter. Made cut at 1516'. TOOH. TIH with casing spear and got 7 point pickup. TOOH - did not have fish. Looked like lst helix of grapple was trying to go in fish. TIH with same grapple and worked bumper sub, jarring down 45 minutes. Pulled 50K and came loose. TOOH - no fish. Put 2' sub on bottom of spear and made up 7-7/8" bit. TIH and tagged top of fish & drilled down 5'. Picked up & have to drill same 5'. Felt like we are outside of pipe. TOOH - grapple broke off & left in hole. TIH with 10-3/4" dress off mill and cut 6'. 1-29-2000 - Continued milling on 8-5/8" casing. Milled to 1492'. TOOH. TIH with 7-7/8" bit & drilled on junk to 1508'. TOOH - bit worn out. TIH with casing spear with 8.13 grapple. Could not get grapple to bite. 1-30-2000 - TOOH with spear - grapple broke off & left in hole. Feel that we sliced casing with shoe & spear went outside pipe. TIH with 4-3/4" tapered mill, bent joint of drillpipe & 1500' of drillpipe. Rigged up swivel. Tried to get in top of casing felt like we were going beside it. TOOH. Rigged up Rotary Wireline. Ran fish finder

log & found top at 1494'. No indication of sliver. Rigged down wireline. TIH with

۰. ۰۰ ۲

YATES PETROLEUM CORPORATION R. L. Burns ATL #1 Section 11-T16S-R35E Lea County, New Mexico

SUNDRY NOTICE CONTINUED (PAGE 3:)

10-5/8" overshot, 8-5/8" grapple and tried to work over top of fish. Caught fish & pulled 30000#. Came loose. TOOH - had 2' piece of casing in overshot. Piece was probably loose on top of casing.

1-31-2000 - TIH with 10-5/8" overshot & try to get over top of casing. Worked 2 hours. TOOH. Indicates that it is going beside casing. TIH with 4-3/4" tapered mill, bent joint of drillpipe & 23 stands of drillpipe & try to get in top of casing. Worked 2 hours - keeps going on outside. TIH with 10-5/8" overshot, knuckle joint jars, drill collars and work overshot over fish. TOOH - had 19' of 8-5/8" fish in grapple. Smooth cut on bottom of fish. TIH with 10-3/4" skirted dress off mill.

2-1-2000 - Dressed off stub. Milled off 4'. TIH with 10-3/4" OD slips joint. Pumped 3 BPM & slipped over stub. Pressured to 750 psi & picked up 1'. Cemented - shown with casing.

2-2-2000 - Cut off 8-5/8" landing joint. Nippled down BOP stack. Dressed off top of 8-5/8". Nippled up casing head. Nippled up BOP stack. TIH with 7-7/8" bit, drill collars and tagged at 1210'. Drilled cement to 1355'. Circulated clean. Shut well in. 2-3-2000 - Continue drilling cement. Went thru splice okay. Fell out of cement at 1552'. TIH and tagged up at 1650'. Washed & pushed junk to 1850'. Would not go down anymore. Running rough with bit - TOOH. TIH with 7-3/4" shoe, mill and push to 1860'. Circulate clean. Shut well in.

2-4-2000 - Started milling with shoe at 1860'. Rough cutting for 1 hour. Junk turned loose. Chased down hole to 2100' & hung up. Thinned mud down. Milled onjunk. Pushed down to 4544'. Cut core. TOOH - had core of redbed, junk, part of 5-1/2" collar, grapple pieces, 2' piece of casing, 6" piece of 2-7/8" upset tubing with threads. Shut well in.

2-5-7-2000 - TIH with 7-7/8" bit & drill collars. Tagged up at 4556'. Drilled on junk. Circulating conventional. Washed junk up into junk basket. Reverse circulated. Recovered a lot of small pieces of metal. Drilled cement to 4591' - smooth drilling. Displaced mud with 9.2# cut brine. TOOH. Laid down drillpipe & drill collars. Installed cap flange on casing head. Released well to production department.

Rusty Klein

Operations Technician June 16, 2000



