

Aetna Eaves Well No. 1-Y

1. Set permanent Bridge Plug in 5 1/2" casing @ \pm 8000'.
2. Spot 15 sacks cement on top of plug.
3. Displace hole with mud laden 10# brine.
4. Determine free point. Cut and pull 5 1/2" casing (Cement top behind 5 1/2" casing @ 6700' by Bond Log).
5. Spot 50 sack cement plug across top of 5 1/2" casing stub.
6. Spot 100 sack cement plug from 4800 to 4400' (across 8 5/8" casing shoe @ 4647'). Tag plug after hardening.
7. Dump 10 sack cement plug in top of 8 5/8" casing.
8. Cut off 13 3/8" and 8 5/8" casings below braden head and weld on 1/4" steel plate.
9. Erect 4" Marker containing information to comply with Statewide Rule 202-A.

Note: Cement was circulated behind 13 3/8" casing set @ 310', and behind 8 5/8" casing set @ 4647'.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

NOV 29 1978

DEC 29 1978
OIL CONSERVATION COMM.
SANTA FE, N. M.