

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-27702
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Snyder "C"
8. Well No. 2
9. Pool name or Wildcat Townsend Permo Upper Penn
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3955' GR

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator Charles B. Gillespie, Jr.	
3. Address of Operator P.O. Box 8 Midland, TX 79702	
4. Well Location Unit Letter G : 2336 Feet From The North Line and 1980 Feet From The East Line Section 6 Township 16-S Range 36-E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3955' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Stuck tubing was shot off @ 10,500'. Left 4 jts. tubing and tac in hole.

1) Set Cast Iron Bridge Plug above perforations and tubing left in hole @ 10,450'. Dump 4 sx cement on plug.

2) Set 100' plug @ 7500'.

3) Set 100' plug @ 8 5/8" shoe @ 4602'. Tag.

4) Set 100' plug @ 5 1/2" liner top @ 4384'. Tag.

5) Set 100' plug @ 13 3/8" shoe @ 358'. Tag.

6) Set 15 sx plug @ surface.

7) Weld 4" marker to surface casing. Clean location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Kevin Widner TITLE Production Manager DATE 8/25/93
TYPE OR PRINT NAME Kevin Widner TELEPHONE NO. 915-683-1771

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

AUG 27 1993