

STATE OF NEW MEXICO  
OIL AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☒ Fee ☐  
5. State Oil & Gas Lease No.  
LG 706

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE APPLICATION FOR PERMIT - (FORM C-101) FOR SUCH PROPOSALS.)

6. Indicate Type of Well OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> P&A		7. Unit Agreement Name
8. Name of Operator Yates Petroleum Corporation		8. Farm or Lease Name Vulture VP State
9. Address of Operator 207 South 4th St., Artesia, NM 88210		9. Well No. 1
10. Location of Well UNIT LETTER: D 330 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 14 TOWNSHIP 15S RANGE 33E NMPM.		10. Field and Pool, or Wildcat Saunders Permo Upper Penn
11. Elevation (Show whether DF, RT, GR, etc.) 4178' GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:  
Set CIBP at 9700' w/35' of cement on top. Cut off 4-1/2" casing at about 7250' and pull.  
Set plug across stub - 100' plug or 35 sacks cement and tag.  
Set plug at 5750-5650' w/35 sacks cement.  
Set plug at 4230-4130' w/50 sacks cement and tag.  
Set plug at 1550-1450' w/25 sacks cement.  
Set plug 20' to surface w/10 sacks cement.

Clean location and install marker.

Load hole w/ 10<sup>th</sup> salt gel

14. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED: Eddie W. Seay TITLE: Production Supervisor DATE: 2-27-84  
Oil & Gas Inspector

FEB 29 1984

CONDITIONS OF APPROVAL, IF ANY: