

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Hamon Oil Company Phone: 915 682-5218		8. Farm or Lease Name McDaniel
3. Address of Operator 611 Petroleum Building, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>14</u> TOWNSHIP <u>16-S</u> RANGE <u>36-E</u> NMPM.		10. Field and Pool, or Wildcat Undesignated
15. Elevation (Show whether DF, RT, GR, etc.) 3895' K.B.		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set permanent B.P. at 11,780'.
- Set 75 sk plug from 11,780' back to 11,120' to cover Strawn zone (top of Strawn at 11,264')
- Pull tubing above top of cement and circulate hole with 10# salt gel mud.
- Pull tubing up to 9,650' and spot 35 sk cement plug (200') from 9,650' to 9,450' (top of Wolfcamp 9,450')
- Cut and pull 5-1/2" casing. Estimate 9,000' recovery.
- Set 50 sk cement plug 50' in and 50' above 5-1/2" casing stub and tag plug.
- Set 50 sk plug (100') from 6,358' to 6,258' at top of Glorietta at 6,258'.
- Set 75 sk plug 50' out and 50' in base of 8-5/8" casing set at 4,896'. Tag plug.
- Set 50 sk plug (100') at top of Salt from 2,200' back to 2,100'.
- Set 50 sk plug (100') at base of 13-3/8" from 467 back to 367'. (13-3/8" casing set at 417'). Tag plug.
- Set 10 sk plug in top of 8-5/8" casing.
- Install dry hole marker.

THIS NOTICE WAS RECEIVED 24
HOURS PRIOR TO THE BEGINNING OF
THE WORK AND WAS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Production Engineer DATE 11-14-84

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE NOV 16 1984

CONDITIONS OF APPROVAL, IF ANY: