

Office

District I

1625 N. French Dr., Hobbs, NM 87240

District II

811 South First, Artesia, NM 87210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources
OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-28826
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Fasken Oil and Ranch, Ltd.		6. State Oil & Gas Lease No. LG-6690
3. Address of Operator 303 W. Wall Ave., Suite 1800, Midland, TX 79701-5116		7. Lease Name or Unit Agreement Name: Superior State
4. Well Location Unit Letter <u>L</u> : <u>1980</u> feet from the <u>South</u> line and <u>910</u> feet from the <u>West</u> line Section <u>7</u> Township <u>15S</u> Range <u>35E</u> NMPM Lea County		8. Well No. 2
10. Elevation (Show whether DR, RKB, RT, GR, etc.) GL 4045'		9. Pool name or Wildcat Morton Wolfcamp

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
 TEMPORARILY ABANDON ☒ CHANGE PLANS ☐
 PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
 CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Proposed TA procedure (Plan to begin on or about 11/20/00):

- 1) RU wireline and packoff.
- 2) RIW w/gauge ring to 10,300'; POW.
- 3) RIW w/5-1/2" CIBP on wireline to 10,280'. Set CIBP. POW.
- 4) RIW w/dump bailer and dump 20' cement on top of CIBP.
- 5) W/wireline, tag cement.
- 6) Pressure test casing to 500 psi. Run 30 minute chart.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Travis A. White TITLE Petroleum Engineer DATE 10/13/00

Type or print name Travis A. White

(This space for State use)

Telephone No. (915) 687-1777

APPROVED BY _____ TITLE _____ DATE _____

Conditions of approval, if any: