

IL CONSERVATION DIVISIC

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103

Revised 10-1-76

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name
2. Name of Operator Brittany Drilling Company	8. Farm or Lease Name Alexander
3. Address of Operator c/o Oil Reports & Gas Services, Inc., Box 763, Hobbs, NM 88241	9. Well No. 1
4. Location of Well UNIT LETTER <u>E</u> <u>2306</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>15S</u> RANGE <u>36E</u> N.M.P.M.	10. Field and Pool, or Wildcat NE Caudill Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3876.3 GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <u>Squeeze & Reperf</u> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Squeezed perfs 10,798-818 thru Baker "R" packer with 100 sacks class "H" cement. Maximum pressure 6,000#. Drilled & cleaned out to 10,865. Perf 10,850 to 10,857 with 2 shots per foot. Treated with 500 gallons MC acid. Swab 99% salt water.

It is proposed to plug & abandon as follows:

Set cast iron bridge plug at 10,650 & cap with 2 sacks cement
Cut & pull 5 1/2" casing from approximately 9200
Spot 100' cement plug across 5 1/2" casing stub
Spot 100' cement plug across 8 5/8" casing shoe at 4800
Spot 100' cement plug across 13 3/8" casing shoe at 420

Set 20 sack plug at surface with regulation marker
Mud between all plugs

Location to be cleaned & leveled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Agent DATE 1/8/85

APPROVED BY _____ TITLE _____ DATE 1/8/85

CONDITIONS OF APPROVAL, IF ANY: