

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- TA'd & A'd on		7. Unit Agreement Name
2. Name of Operator Amerada Hess Corporation		8. Farm or Lease Name State 4
3. Address of Operator Drawer D, Monument, New Mexico 88265		9. Well No. 1
4. Location of Well UNIT LETTER <u>W</u> <u>525</u> FEET FROM THE <u>South</u> LINE AND <u>1950</u> FEET FROM THE <u>East</u> LINE, SECTION <u>4</u> TOWNSHIP <u>16S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat NE Lovington Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3820.8' GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to run 5-1/2" CIBP set at 11,550' & cap w/35' Class H cement. RU casing pulling unit & tools. Pick up 5-1/2" csg. & calculate stretch & free point. Run csg. cutter on wireline & cut 5-1/2" csg. TOH w/same & lay down. Run 2-7/8" tbq. & circ hole w/mud. Spot 100' Class H cement across 5-1/2" csg. stub. WOC. Check top of cement & spot 100' each of Class H cement as follows: cement plug across ABO Zone at 8502', cement plug across Glorieta at 6563', cement plug across San Andres at 5162', cement plug across 8-5/8" shoe at 4400' & WOC. Check top of cement, spot 100' Class H cement plug across Salt Section at 2200'. Spot 10 sks. cement plug at surface. Remove well head & install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. L. White, Jr. TITLE Supv. Adm. Svc. DATE 12-16-87

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY DATE TITLE DATE DEC 16 1987

CONDITIONS OF APPROVAL, IF ANY: