

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL API NO. 30-025-34616
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. 24566
7. Lease Name or Unit Agreement Name: Townsend "3" State
8. Well No. 8
8. Pool name or Wildcat South Big Dog (Strawn)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☐ Gas Well ☐ Other ~~Temporarily Abandoned~~

2. Name of Operator
Ocean Energy Resources, Inc.

3. Address of Operator
4305 N. Garfield, Suite 200A, Midland, Texas, 79705

4. Well Location

Unit Letter N : 660 feet from the South line and 2310 feet from the West line

Section 3 Township 16-S Range 35-E NMPM County Lea

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
4011 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1. MIRU workover rig.
2. RIH w/ tbg & retrieve RBP @ 4515'.
3. RIH w/ tbg & tag TD @ 11720'. Circ hole w/ 10# brine w/ 25# gel/bbl.
4. POOH to 11620', spot 50 sx cement from 11620' to 11420'.
5. WOC & tag plug @ 11420'.
6. Spot 50 sx cement plugs @ 9400'-9600', 7400'-7600', 6300'-6500'.
7. Spot 25 sx intermediate shoe plug from 4675'-4775'.
8. WOC & tag plug @ 4675'.
9. Spot 25 sx cement plug from 1675'-1775'.
10. Spot 25 sx surface shoe plug from 370'-470'.
11. WOC & tag plug @ 370'.
12. Spot 15 sx surface plug from 0'-60'.
13. Cut off wellhead & weld on dry hole marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CEMENT TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE John M. Stinson TITLE Area Manager - Permian Basin DATE 04/27/00

Type or print name John M. Stinson
(This space for State use)

Telephone No. 505/887-5158

APPROVED BY DATE
Conditions of approval, if any:

2000

2000
2000
2000
2000
2000