

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.C.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)OIL WELL ☒ GAS WELL ☐ OTHER ☐Name of Operator Damson Oil CorporationAddress of Operator 3300 North "A", Building 8, Suite 100, Midland, TX 79705Location of Well
UNIT LETTER H 1980 FEET FROM THE North LINE AND 600' FEET FROMTHE East LINE, SECTION 29 TOWNSHIP 19S RANGE 32E NMPM.15. Elevation (Show whether DF, RT, GR, etc.)
3560' GL12. County
LeaCheck Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:PERFORM REMEDIAL WORK ☒
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐PLUG AND ABANDON ☐CHANGE PLANS ☐OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐COMMENCE DRILLING OPNS. ☐CASING TEST AND CEMENT JOB ☐OTHER ☐ALTERING CASING ☐PLUG AND ABANDONMENT ☐

16. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work on the following procedure began on 9/29/86 to prevent additional formation damage from a casing leak. The Hobbs office was notified on 10/1/86.

1. Rig up pulling unit. Pull out of hole with rods and pump. Release rubbing anchor and lower tubing to tag top of fish @ 11,322'. Pull out of hole.
2. Run in hole w/packer and retrievable bridge plug on 2-3/8" workstring. Set RBP @ \pm 11,270', load hole with brine and test. Pump 4 sacks sand on top of RBP and then locate leak. Pull out of hole.
3. Run in hole with cement retainer and set 100' above leak. Rig up cementers and squeeze leak per recommendation. Pull out of hole with tubing and wait on cement 24 hrs.
4. Rig up reverse unit. Run in hole with bit, drill collars and workstring. Drill out retainer and cement. Test squeeze to 1000 psi. Drill out any cement that is on top of RBP. Pull out of hole.

16. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Kautz TITLE Production Technician DATE Oct. 1, 1986Orig. Signed by
Paul Kautz
GeologistAPPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE OCT 6 1986