

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-5310	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Cities Service Oil Company	8. Farm or Lease Name Ohio A-State
3. Address of Operator Box 69 - Hobbs, New Mexico	9. Well No. 6
4. Location of Well UNIT LETTER <u>H</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>32</u> TOWNSHIP <u>17S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat Corbin Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4051 GR	12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned on August 1, 1970 in the following manner:

1. Set a CI bridge plug @ 3700 (7" set @ 3735 w/50 sacks)
2. Loaded hole with mud laden fluid.
3. Set a 5 sack cement plug on top of BP @ 3700-3660.
4. Cut and pulled 1750' of 7" casing.
5. Set a 50 sack cement plug @ 1800-1650 (1/2 in and 1/2 out of 7" csg. stub @ 1750)
6. Set a 50 sack cement plug @ 1425-1300 (1/2 in and 1/2 out of 8 5/8" casing set @ 1368 w/100 sacks).
7. Set a 10 sack cement surface plug @ 30-0 with a 4" pipe extending 4' above the surface to designate a P & A location.
8. The location has been cleaned of all debris and equipment and is ready for final inspection.

9. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

TO \_\_\_\_\_ TITLE District Admin. Supervisor DATE 1/12/71

BY John W. Runyan TITLE Geologist DATE MAR 31 1971

NO. OF APPROVAL, IF ANY: \_\_\_\_\_