

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals & Natural Resources Department

Form C-103  
Revised 1-1-89

**DISTRICT I**  
P. O. Box 1980, Hobbs, NM 88240

**DISTRICT II**  
P. O. Drawer DD, Artesia, NM 88210

**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**

P. O. Box 2088  
Santa Fe, NM 87504-2088

WELL API NO.  
30-025-01510

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
B-2148

7. Lease Name or Unit Agreement Name  
Caprock Maljamar Unit

8. Well No.  
85

9. Pool name or Wildcat  
Maljamar Grayburg San Andres

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1 Type of Well:  
OIL WELL ☒ GAS WELL ☐ OTHER ~~Water Injection Well~~

2. Name of Operator  
The Wiser Oil Company

3. Address of Operator  
P.O. Box 2568 Hobbs, New Mexico (505) 392-9797

4. Well Location  
Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line  
Section 21 Township 17S Range 33E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
4177'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Wiser requests approval to plug and abandon the well by the procedure listed below.

1. POH w/production equipment. TIH w/CIBP & set @ 4200'. Current perforations @ 4249'-4443'.

2. Dump 25 sks. cmt. on CIBP. Tag cmt. plug.

3. Circulate abandonment mud.

4. Perforate casing @ 1375' & circulate cmt. to surface.

5. Set 25 sks. cmt. plug @ 700'.

6. Set 10 sks. cmt. @ 50' from surface.

7. Install dry hole marker. Clean location

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. M. Jones TITLE Production Superintendent DATE August 21, 2000

TYPE OR PRINT NAME Mike Jones TELEPHONE NO. (505) 392-9797

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_