

DISTRICT I

P. O. Box 1980, Hobbs, NM 88240

DISTRICT II

P. O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P. O. Box 2088
Santa Fe, NM 87504-2088

WELL API NO.

30-025-01528

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

B-2229

7. Lease Name or Unit Agreement Name

Caprock Maljamar Unit

8. Well No.

88

9. Pool name or Wildcat

Maljamar Grayburg San Andrea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL ☐

GAS ☐

WELL ☐

WELL ☐

OTHER ☐ WIW

2. Name of Operator

The Wiser Oil Company

3. Address of Operator

P.O. Box 2568 Hobbs, New Mexico 88241 (505) 392-9797

4. Well Location

Unit Letter D : 330 Feet From The North Line and 330 Feet From The West Line

Section 28 Township 17S Range 33E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4186' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Wiser requests approval to Plug and Abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 358'
Perfs: 4278'-4476'

Production Casing: 5-1/2" @ 4565'

1. TIH w/tbg. & tag cmt. @ cmt. ret. @ 2900'.
2. Drill out cmt. & ret. Pressure test csg. to 500#.
3. TIH to 3660' & tag CIBP. Drill out CIBP & clean out to 4200'.
4. TIH & set CIBP @ 4200'. Cap w/25' cmt. Tag cmt.
5. Circulate abandonment mud to surface.
6. POH to 1600' & set 50' plug. SI
7. Tag cmt. plug.
8. POH to 600' & set 50' plug. SI
9. Tag cmt. plug.
10. Perforate csg. @ 360'. Circulate cmt. to surface.
11. Set 50' cmt. plug @ surface.
12. Install dry hole marker.
13. Clean location.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

S.M. Jones

TITLE

Superintendent

DATE

October 18, 2001

TYPE OR PRINT NAME

Mike Jones

(This space for State Use)

APPROVED BY

TITLE

DATE

Oct 20 2001

MP