	<b>3</b> ·					
Form 3160-5 (November 1983)	UN. D STAT		SUBMIT IN TRIPLICATE®	Form approved. Budget Bureaus No. 1004-0135 Expires August 31, 1985		
(Formerly 9-331)	DEPARTMENT OF THE INTERIOR (Other Instructions on re- verse side)  BUREAU OF LAND MANAGEMENT		5 LEASE DESIGNATION AND SETAL NO. NMLCO29489A			
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.				6. IF INDIAN, ALLOTTEE OR TRIBE NAME		
Use "APPLICATION FOR PERMIT" for such proposals.)				7.UNITAGREEMENTNAME		
OIL WEIL OTHER						
OXY USA INC.				8 FARM OR LEASE NAME FEDERAL AH		
3. ADDRESS OF OPERATOR P.O. BOX 50250 MIDLAND, TX 79710				9 WELL NO.	4	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*  See also space 17 below.)				10. HELDAND POOL, ORWI	CORBIN YATES	
1980 FSL 1980 FEL				11.SEC, T, R, M, OR BLK AND SURVEY OR AREA		
				SEC 9 T18S R33E		
14. PERMIT NO. 30-625-0	1542	wheter DF, RT, GR, etc.)		12 COUNTY OR PARISH	13. STATE NM	
600150159300S01  School Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature of Notices Report or Check Appropriate Roy To Indicate Nature Nature Or Check Appropriate Roy To Indicate Nature Nature Or Check Appropriate Roy To Indicate Nature						
Clieck Appropriate Dox to indicate relative of respect, or				EQUENT REPORT OF:		
				-	<u> </u>	
Testwater shut-off Fracture treat Shoot or acidize	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON*		MATER SHUT-OFF FRACTURE THEATMENT SHOOTING OR ACIDIZING (Other)	REPARING ALTERING ABANDONIA	CASING	
REPARWELL CHANGE PLANS (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)						
TO DESCRIPE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and five pertinent dates, including estimated date of starting any						
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*						
TD - 4324' PBTD - 3520' YATES PERFS - 3435' - 3460'						
IT IS PROPOSED TO P&A THIS WELL IN THE FOLLOWING MANNER:						
				•		
SEE OTHER SIDE:						
	•					
	,					
18. Thereby certify that the forego	ying is true and correct				**************************************	
SIGNED JOH	EMUS	_ TITLEENGINE	ERING ADVISOR	DATE	•	
	/ \//1					

\*See Instructions on Reverse Side

DATE 7/14/92

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

## Federal AH #4 Plugging Procedure

12 3/4" @ 275' cmtd w/ 150 sx Cmt Circ Casing:

Cmt Circ 8 5/8" @ 1539' cmtd w/ 625 sx

5 1/2" @ 4324' cmtd w/ 215 sx TOC est @ 2685'

TD: 4324' PBTD: 3520'

Perfs:

Yates (3435' - 3460') Top @ 1600' Base @ 2750' Salt:

1.) Notify BLM in Hobbs prior to commencing plugging procedure.

- 2.) MIRU pulling unit. TOOH and LD rods and pump. ND WH, NU BOP. TOOH w/ tbq.
- 3.) RU wireline and set CIBP @ 3400'. Dump 4 sx cmt on top of CIBP.
- 4.) TIH w/ tbg open ended and circ hole w/ 9 lb/gal mud laden fluid. TAG PLUG.
- 5.) PU on the to 2800' and spot 15 sx Class C cmt from 2800' to 2655'. TOOH W/ tbg. AFTER TAGGING THE PLUG.
- 6.) RU wireline and perforate 2 squeeze holes @ 1650'. Tie unto 5 1/2" casing, open bradenhead and establish circualtion through squeeze holes. Mix and pump 500 sx Class C cmt down the casing and circulate cement out the bradenhead. LEAVE CEMENT INSIDE 51/2: CASING TO THE SURFACE.
- 7.) Cut off WH, install dry hole marker, clean up location, and rip and re-seed location.