

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name E. K. Queen Unit Tr. 1	
9. Well No. 2	
10. Field and Pool, or Wildcat E. K. Yates 7/Rivers Q.	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Mobil Oil Corporation	3. Address of Operator Three Greenway Plaza East, Suite 800, Houston, Texas 77046	4. Location of Well UNIT LETTER <u>J</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>13</u> TOWNSHIP <u>18-S</u> RANGE <u>33-E</u> NMPM.	15. Elevation (Show whether DF, RT, GR, etc.) 3963 DF
--	--	--	--	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Run 5½" cement retainer on tubing to 4300'± and squeeze Queen perfs (4332-4372') with 50 sx. Class "H" neat cement.
- Pull out of retainer and spot 5 sx neat cement on top of retainer.
- Load hole with 9.5#/gal fluid.
- Pull tubing to 3030'± and spot 25 sx Class "H" neat cement.
- Pull out of hole and run "free-point" log and pull all available 5½" casing.
- Run tubing to 1700' or 50' below casing cut (use deeper depth) and spot 60 sx Class "H" neat cement.
- WOC
- Check cement to be no less than 1600' or 50' above casing cut. (use shallower depth).
- Pull tubing to 350' and spot 35 sx Class "H" neat cement.
- WOC
- Check cement top to be no less than 250'.
- Set 10 sx surface plug with Class "H" neat cement.
- Erect monument and clear location.

NOTE: Verbal approval from U.S.G.S.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Authorized Agent</u>	DATE <u>1-3-77</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u>1977</u>

CONDITIONS OF APPROVAL, IF ANY: