

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☐ other ☒ WIW
well well2. NAME OF OPERATOR
Mobil Oil Corporation3. ADDRESS OF OPERATOR
Three Greenway Plaza Ea., Suite 800, Houston4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: Unit C, 330' FNL, 2310' FWL
AT TOP PROD. INTERVAL: 4327-4346
AT TOTAL DEPTH: 4374

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☐
☐
☐
☐
☐
☐
☐

RECEIVED

NOV 14 1977

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

U. S. GEOLOGICAL SURVEY
DALLAS, TEXAS

5. LEASE

New Mexico 04591

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

E. K. Queen Unit, Tr. 6

9. WELL NO.

2

10. FIELD OR WILDCAT NAME

E. K. Yates 7/Rivers Queen

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 24, T-18S, R-33E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

14. API NO.

30 025 01642

15. ELEVATIONS (SHOW DF, KDB, AND WD)

3922 GR

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

P & A, subject well no longer of economic value. See attachment for procedure.

Subsurface Safety Valve: Manu. and Type

Set @ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED A. R. Saenz TITLE Authorized Agent DATE November 9, 1977

(This space for Federal or State office use)


APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side



- (1) Pull tbg and pkr.
- (2) Run 5½" cement retainer and set @ 4300'± sqz Queen OH (4349-4374') w/100 sx Class H neat cmt. Displace to cmt ret.
- (3) Cap cmt. retainer w/5 sx Class H neat cmt.
- (4) Load hole w/9.5 ppg fluid.
- (5) Run free pt. and pull available 5½" csg.
- (6) Spot 100' plug Class H neat cement in and out of cut off pt. Check cmt top to be @ least 50' above casing cut.
- (7) Run free pt and pull all available 8-5/8" casing.
- (8) Spot Class H neat cmt plug from 1580'-1700' to cover 8-5/8" casing shoe and anhydrite zone. Check cmt top to be @ 1580'.
- (9) Spot 100' plug Class H neat cement in and out of cut off pt. Check cmt top to be @ least 50' above casing cut.
- (10) Spot 100' plug Class H neat cmt from 200'-300' to cover 13-3/8" casing shoe check cmt top to be @ 200'.
- (11) Spot 10 sx Class H neat cmt @ surface.
- (12) Erect monument and clear location.