

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

BRIDGES STATE

8. Well No.

92

9. Pool name or Wildcat

VACUUM GRAYBURG SAN ANDRES

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL

WELL ☒

GAS

WELL ☐

OTHER

2. Name of Operator

Mobil Producing Tx. & N.M. Inc.*

3. Address of Operator

*Mobil Exploration & Producing U.S. Inc., as Agent for
Mobil Producing TX. & N.M. Inc., P. O. Box 633, Midland, TX 79702

4. Well Location

Unit Letter 0 : 660 Feet From The SOUTH Line and 1980 Feet From The EAST Line

Section 3

Township 17S

Range 34E

NMPM LEA

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4057 GL 4070 KB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU MAYO MARRS. ND WH. POH W/RODS & PUMP. NU BOP. POH W/TBG. LD SAME.

2. RIH W/CIBP FOR 5-1/2 14# CASING ON 2-3/8 WS. SET CIBP @ 4600 & CAP W/35 CMT. PU WS TO 4000.WOC

3. RIH W/WS TO 4550. CIRC WELLBORE W/10 PPG GELLED BRINE. PU WS TO 1750.

4. RU CMT SERV. SPOT PLUG OF 21 SX CMT FROM 1750-1550 ACROSS BASE OF 8-5/8 CSG & TOP OF SALT AT 1600.
DISPLACE TBG W/6 BBLs 10 PPG GELLED BRINE. PU TBG AND WOC 8 HRS. TAG CMT PLUG TOP AT 1550. PU TBG TO
50 FT.

5. SPOT 5 SX (50 FT) TO SURFACE. POH W/WS. WOC. MAKE SURE CMT IS AT TOP OF PIPE.

6. ND BOP. RD PU. CUT CAS 3 FT BELOW GROUND LEVEL. WELD A STEEL PLATE ON CAS STUB. ERECT P&A MARKER
W/WELL NAME AND PLUGGED DATE. FILL CELLAR AND CLEAN SURFACE LOCATION.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

J. W. DIXON

TITLE

Engineering Technician

DATE 4/5/91

(915)

TELEPHONE NO. 688-2452

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

1991