

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1080
7. Unit Agreement Name -
8. Farm or Lease Name New Mexico 'M' State
9. Well No. 1
10. Field and Pool, or Wildcat Vacuum Grayburg San Andres
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator TEXACO Inc.
3. Address of Operator P.O. Box 728, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER F , 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 1 TOWNSHIP 18S RANGE 34E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4,003' DF



16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Run 450' 17# Flush joint liner w/liner hanger at 4,450 and top at 4,000'.
2. Pump 25 sx Class 'C' cement w/5# salt/sk and 1/4# flocele/sk.
3. Run cement retainer in 7" casing and set at 3,800'.
4. Squeeze top of liner w/100 sx Class 'C' cement w/8# salt/sk. Resqueeze if necessary.
5. Drill out retainer and cement and deepen hole to 4,710'.
6. Run GR-N log 4,000 - TD.
7. Acidize w/4,000 gals 15% NEA if necessary.
8. Swab, test and return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE Assistant District Superintendent	DATE February 25, 1972
APPROVED BY 	TITLE Dist. 1, Supv.	DATE FEB 28 1972
CONDITIONS OF APPROVAL, IF ANY:		