

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

MAY 11 11:43 AM '67

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
Unknown

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
Sunray DX Oil Company	New Mexico "H" State
3. Address of Operator	9. Well No.
P. O. Box 1416, Roswell, New Mexico	2
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER M 660 FEET FROM THE West LINE AND 660 FEET FROM	E. K. Queen
THE South 8 TOWNSHIP 18S RANGE 34E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4072 G.L.	Lea

16.

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

### SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input checked="" type="checkbox"/>
OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Loaded hole with mud laden fluid.
2. Spotted 25 sx cement plug from 4404-4300'.
3. Layed down tubing.
4. Shot casing off at 1640'. Layed down casing.
5. Spot 25 sx cement plug 2010-1910'.
6. Spot 25 sx cement plug from 1650-1550'.
7. Spot 25 sx cement plug from 245-145'.
8. Spot 10 sx plug in top of surface casing.
9. Placed identification marker in top of pipe.
10. Filled pits, leveled location and removed excess material from wellsite.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Hastings TITLE District Engineer DATE May 8, 1967

APPROVED BY Leslie H. Clements TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: