

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
1065	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - II" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Marathon Oil Co.		State EK "A"
3. Address of Operator		9. Well No.
P. O. Box 2409 Hobbs, N. M. 88240		6
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER C 330 FEET FROM THE North LINE AND 1650 FEET FROM		EK Queen
THE West LINE, SECTION 17 TOWNSHIP 18-S RANGE 34E N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4065 GR		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well is presently plugged back to 4350' with a Baker Model "N" Bridge Plug capped with cement.

Plan to:

1. Set cement retainer at 3600'
2. Abandon perfs 3634'-3642' with 40 sacks cement below and cap with 10 sacks above retainer
3. Cut off casing at 2700'
4. Place plug at top of 5 1/2" (2700') with 25 sacks cement in 25 sacks out
5. Place plug at bottom of 10 3/4" (380') with 25 sacks cement in and 25 sacks out
6. Spot 10 sacks back to the surface of 10 3/4" casing
7. Cut off pipe 3' below surface and weld on plate
8. Erect marker and clean up location.

All plugs will be separated by mud-laden fluid

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. A. Viter Jr. TITLE Operations Superintendent DATE 6/20/74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: