Form 9-331 Doc. 1973 UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY	Form Approved. Budget Bureau No 42-R1424 S. 1EASE NM-04591 C. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir, Use Form 9-232-C for such proposals.)	7. UNIT AGREEMENT NAME E-K Queen Unit Tract 6 8. FARM OR LEASE NAME
2. oil well Well Other 2. NAME OF OPERATOR	9. WELL NO. 5 10. FIELD OR WILDCAT NAME
Mobil Producing TX. & N.M. Inc. 3. ADDRESS OF OPERATOR Nine Greenway Plaza, Suite 2700, Houston, Texas 77046 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	E-K Yates Seven Rivers Queen 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
below.) AT SURFACE: 660'FNL & 609.5'FWL of Sec. 19 AT TOP PROD. INTERVAL: Same as surface AT TOTAL DEPTH: Same as surface	Sec. 19, T18S, R34E 12. COUNTY OR PARISH' 13. STATE Lea New Mexico 14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF. KDB, AND WD) 3976.6 GR, 3979 DF
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL PULL OR ALTER CASING MULTIPLE COMPLETE CHANGE ZONES ABANDON* (other)	(NOTE: Report results of multiple completion 22 zone change on Form 9-330.) Change on Form 9-330.) Change on Form 9-330.
 27. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly stating any proposed work. If well is measured and true vertical depths for all markers and zones pertine 4411, Queen OHZ 4380-4411, Casing Record 13-3/8 @ 2 Set a cement retainer at 4360' and squeeze Queen Cap the retainer with 5 sacks cement from 4360 to Spot 11 sacks Class C cement from 3050 to 2950'. Perf the 5-1/2 casing with 4 shots at 1750'. Set between the 5-1/2 & 8-5/8 casing with 35 sacks Cl 5 sacks cement from 1700 to 1650'. Cut and pull approximately 1500' of the 5-1/2 cas Perf the 8-5/8 casing with 4 shots at 300'. Set a between the 8-5/8 & 13-3/8 casing with 14 sacks Cl 4 sacks cement from 250 to 200'. Spot 14 sacks class C cement from 50 to surface. Erect a P&A marker and clean the location. 	directionally drilled, give subsurface locations and int to this work.)* (50, 8-5/8 @ 1703, 5-1/2 @ 4380 OHZ with 25 sacks Class C cement. (4310'.) a cement retainer at 1700', squeeze ass C cement. Cap the retainer wi ing. cement retainer at 250'. squeeze
Subsurface Safety Valve: Manu. and Type	Set @ Ft
38. I hereby certify that the foregoing is true and correct BIGNED <u>APPROVED</u> THE <u>Authorized A</u> <u>APPROVED</u> (The space for Federal or State of APPROVED (This space for Federal or State of State o	flice upe)
CONDITIONS OF APPROVAL IF ANY: FEB 2 1984	

:

7