

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

5a. Indicate Type of Lease

State ☒ Fee ☐

5. State Oil & Gas Lease No.

B-1113-1

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|---|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> | 7. Unit Agreement Name Central Vacuum Unit- |
| Name of Operator TEXACO Inc. | 8. Farm or Lease Name Central Vacuum Unit |
| Address of Operator P.O. Box 728, Hobbs, NM 88240 | 9. Well No. 112 |
| Location of Well UNIT LETTER L 2310 FEET FROM THE South LINE AND 330 FEET FROM THE West LINE SECTION 6 TOWNSHIP 18-S RANGE 35-E N.M.P.M. | 10. Field and Pool, or Wildcat Vacuum Grayburg - San Andres |
| 15. Elevation (Show whether DF, RT, GR, etc.) 3994' (DF) | 12. County Lea |

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

| | | | |
|--|--|--|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOBS <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP.
2. Spot 500 sx. cement plug @ 2900'.
3. Perforate 5-1/2" csg @ approx. 1600' (top of salt). Set cement retainer @ 1500'.
4. Squeeze perforations @ 1600' w/200 sx. Class "H" cement.
5. Spot 10 sx. cement cap on top of cement retainer @ 1500'.
6. Spot 20 sx. cement plug @ 500'.
7. Spot 20 sx. cement plug @ 350'.
8. Spot 20 sx. cement plug @ surface.
9. Install dry hole marker & clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *J. A. Schuff* TITLE Asst. Dist. Supt. DATE 11-3-80
APPROVED BY *J. A. Schuff* TITLE Asst. Dist. Supt. DATE 11-3-80
CONDITIONS OF APPROVAL, IF ANY: