

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
L-1568

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name	
2. Name of Operator	8. Farm or Lease Name	
AZTEC OIL & GAS COMPANY	State "Q"	
3. Address of Operator	9. Well No.	
P. O. Box 837, Hobbs, New Mexico 88240	1	
4. Location of Well	10. Field and Pool, or Wildcat	
UNIT LETTER G 1980 FEET FROM THE North LINE AND 1980 FEET FROM	Arkansas Jct. - Queen	
THE East LINE, SECTION 12 TOWNSHIP 18-S RANGE 36-E N.M.P.M.		
11. Elevation (Show whether DF, RT, GR, etc.)	12. County	
3785 DF	Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug & Abandon this well in the following manner:

1. Set 100' (25 sxs) cement plug from 4600-4400' (Queen).
2. Load Hole with 10# mud laden fluid.
3. Set 100' (25 sxs) cement plug from 3147-3047' (Yates).
4. Set 100' (25 sxs) cement plug from 2057-1957' (Salt).
5. Set 100' (25 sxs) cement plug in and out of Surface Pipe.
6. Set 10 sxs cement plug at Surface with Dry Hole Marker, Clear & Level Location.
7. If Pipe is pulled, set 100' (25 sxs) cement plug in and out of Stub.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:

SIGNED **LESTER L. DUKE**

TITLE **District Superintendent**

DATE **Dec. 27, 1972**

APPROVED BY *Nathan E. Olegg*
CONDITIONS OF APPROVAL, IF ANY:

TITLE

OIL & GAS INSPECTOR

DATE

DEC 29 1972