

1970

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

## NEW MEXICO OIL CONSERVATION COMMISSION

3-MMOC  
1-File

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT..." (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator <b>GETTY OIL COMPANY</b> 3. Address of Operator <b>P.O. Box 249, Hobbs, New Mexico 88240</b> 4. Location of Well UNIT LETTER <b>C</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>23</b> TOWNSHIP <b>18 S</b> RANGE <b>36 E</b> N.M.P.M. 15. Elevation (Show whether DF, RT, GR, etc.) <b>3805 DF</b> 12. County <b>Lee</b>	7. Unit Agreement Name 8. Name of Lease Name <b>STATE "AR"</b> 9. Well No. <b>No. 1</b> 10. Field and Pool, or Wildcat <b>Ark. Junction Queen</b>
---	---

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The well has depleted the Queen Gas Reserves and has no remedial potential. It is proposed to P & A as follows:

Set 2-7/8" CI Bridge Plug at 4,550', dump 10' cement or lay 15 sack cement plug from 4500' to 4620'. Cut 2-7/8" casing where it is free, top of cement by TL was @ 3000'.

Lay 25 sack cement plug at the 2-7/8" stub.

Lay 25 sack cement plug in and out of 7" casing from 1980' to 1800'.

Lay 10 sack cement plug at the surface.

Erect P & A marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY:

SIGNED C. L. Wade TITLE Area Superintendent DATE February 27, 1970

APPROVED BY [Signature] TITLE  DATE

CONDITIONS OF APPROVAL, IF ANY:

WTA/bh