

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-76

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		N. HOBBS (G/SA) UNIT
3. Address of Operator		8. Farm or Lease Name
P. O. BOX 991, HOUSTON, TEXAS 77001		SECTION 19
4. Location of Well		9. Well No.
UNIT LETTER <u>G</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM		10. Field and Pool, or Wildcat
THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>18-S</u> RANGE <u>38-E</u> N.M.P.M.		HOBBS (G/SA)
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3662' GL		LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data.

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>PERFORATE, SQUEEZE, AND ACIDIZE</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Clean out to T.D. @ 4260'.
- Plug back from T.D. to 4150'± w/20-40 sand.
- Perforate 4 squeeze perforations @ 4140'.
- Squeeze cement perforations @ 4140' w/50 sx Class "C" cmt containing 2% CaCl₂ + 500 gals flochek + 500 gals 10% CaCl₂ water. WOC 24 hours.
- Drill out cement and pressure test squeeze to 500 psi. Clean out sand to T.D.
- Acidize perforations 4180' to 4228' and open hole (4244' to 4260') w/4500 gals of 15% HCl-NEA.
- Install production equipment and return well to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A. J. FORE</u>	TITLE <u>SUPERVISOR REG. & PERMITTING</u>	DATE <u>MARCH 6, 1984</u>
ORIGINAL SIGNED BY <u>JOHN SEXTON</u>		
DISTRICT 1 SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		

MAR 13 1984

RECEIVED
MAR 12 1984
O.C.D.
HOBBS OFFICE