

NF      EXICO OIL CONSERVATION C      ISSION  
Santa Fe, New Mexico

### MISCELLANEOUS NOTICES

Submit this notice in triplicate to the Oil Conservation Commission or its proper agent before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or its agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate nature of notice by checking below:

NOTICE OF INTENTION TO TEST CASING SHUT-OFF		NOTICE OF INTENTION TO SHOOT OR CHEMICALLY TREAT WELL
NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO PULL OR OTHERWISE ALTER CASING
NOTICE OF INTENTION TO REPAIR WELL	<b>X</b>	NOTICE OF INTENTION TO PLUG WELL
NOTICE OF INTENTION TO DEEPEN WELL		

**Midland, Texas**

**October 20, 1936**

Place

Date

OIL CONSERVATION COMMISSION,  
Santa Fe, New Mexico.

Gentlemen:

**California Company**

Following is a notice of intentiton to do certain work as described below at the

**H. D. McKinley**

**1**

**NW 1/4**

Company or Operator \_\_\_\_\_ Well No. \_\_\_\_\_ in \_\_\_\_\_  
of Sec. **20**, T. **18-S**, R. **38-E**, N. M. P. M., **Hobbs** Field,  
**Lea** County.

### FULL DETAILS OF PROPOSED PLAN OF WORK

FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS OF THE COMMISSION

(See recommendations attached)

Approved \_\_\_\_\_, 19\_\_\_\_  
except as follows:

OIL CONSERVATION COMMISSION,

By \_\_\_\_\_

Title \_\_\_\_\_

### THE CALIFORNIA COMPANY

Company or Operator

By **HARVEY HARDISON** P.O.  
Position **Sup't. of Prod. & Development**

Send communications regarding well to

Name **THE CALIFORNIA COMPANY**  
Address **Midland, Texas**

Seeinley #1.

-4-

Recommendations:

1. Pull 3" tubing and flow valves.
2. Run Schlumberger surveys to definitely locate top of water producing horizon. This will necessitate two surveys, a porosity-resistivity survey and a temperature survey.
3. Set wall packer above water producing horizon on 3" tubing with perforations above packer. Determine well capacity from pays above packer seat.
4. Pull packer, remove perforations, and re-run open ended with back-off nipple above packer.
5. Set packer and pump in cement through tubing to fill space below packer.
6. Back off from packer, re-run 3" tubing and put well on test to determine water shut-off after cement has set. If necessary, solidize upper pays.

PLANNED REWORKING P.O.

10/1m

cc: A. J. Hawley  
E. M. Taylor (direct)  
Hobbs