

OF COPIES RECEIVED	
DISTRIBUTION	
SAFETY	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator <b>Chevron Oil Company</b>	8. Farm or Lease Name <b>L. D. McKinley</b>
3. Address of Operator <b>P. O. Box 1660, Midland, Texas 79701</b>	9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>E</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>20</b> TOWNSHIP <b>18-S</b> RANGE <b>33-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Hobbs (San Andres)</b>
11. Elevation (Show whether DF, RT, GR, etc.) <b>3658' DF</b>	12. County <b>Lea</b>

15. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods and tubing.
2. Locate hole in 7" casing with retrievable bridge and packer.
3. Squeeze hole with approximately 250 sacks cement.
4. Drill out cement, and test squeeze to 1000 psi.
5. Acidize perforations 4216-4224 with 2000 gals. 15% HFA.
6. Place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. A. Goudeau TITLE Area Supervisor DATE May 13, 1975

APPROVED BY Mr. L. H. Hines TITLE Area Supervisor DATE May 13, 1975

CONDITIONS OF APPROVAL, IF ANY: