

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name <b>Fowler</b>
9. Well No. <b>5</b>
10. Field and Pool, or Wildcat <b>Bowers Svn.Rvs.</b>
12. County <b>Lea</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>CITIES SERVICE OIL COMPANY</b>
3. Address of Operator <b>P.O. Box 69, Hobbs, New Mexico 88240</b>
4. Location of Well UNIT LETTER <b>A</b> <b>380</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM THE <b>East</b> LINE, SECTION <b>31</b> TOWNSHIP <b>18S</b> RANGE <b>38E</b> NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

**3647 DF**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well in the following manner:

1. Rig up pulling unit and check to see if hole will hold fluid.
2. Pull rods, pump and tubing
3. (a) If hole will hold fluid proceed with step No. 4  
(b) If hole will not hold fluid set BP @ 3100' and dump a 2 sack cement plug on top of BP (5½" set and cemented @ 3160') and skip step No. 4.
4. Load hole with mud laden fluid and spot a 25 sack cement plug ½ below and ½ above casing shoe @ 3160'.
5. Spot a 25 sack cement plug ½ above and ½ below the top of salt @ 1500'
6. Set a 10 sack cement surface plug @ approx. 30' - 0' with a 4" dry hole marker extending 4' above ground.
7. Clean location of all equipment and debris.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE **Dist. Admin. Supervisor** DATE **Jan. 27, 1972**

PROVED BY **Joe D. Ratney**  
Dist. I, Supv.

TITLE \_\_\_\_\_ DATE **JAN 28 1972**

CONDITIONS OF APPROVAL, IF ANY: