

Attachment - W. D. Grimes (West) No. 7  
Form C-102

Propose to repair 7" casing leak, replace formation packer, and wash open hole with 500 gallons of mud acid.

Propose to conduct work in the following manner:

1. Kill well with mud, pull tubing and formation packer.
2. Run wire line bridge plug and set in base of 7" casing.
3. Run retrievable cementer and locate leak interval.
4. Perforate 7" casing with 2 holes at approximately 1200' (calculated top of cement behind 7" casing at 1300' from surface).
5. Run cement retainer and set approximately 50' above perforations.
6. Cement 7" - 9-5/8" annulus from 1200' to surface.
7. Connect to 13-3/8" - 9-5/8" annulus and fill the 13-3/8" - 9-5/8" annulus with cement.
8. Wait on cement.
9. Drill out retainer and cement and pressure test 7" casing with 1000 psi for 30 minutes.
10. If pressure holds, drill out bridge plug.
11. Run Gamma Ray and Neutron and Caliper log.
12. Set formation packer near top of San Andres at 3975'.
13. Wash open hole with 500 gallons of mud acid.
14. Return well to production.