

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
310 Old Santa Fe Trail, Room 206  
Santa Fe, New Mexico 87503

WELL API NO.	30-025-07947
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	LANEY REESE
8. Well No.	1
9. Pool name or Wildcat	HOBBS SAN ANDRES, EAST
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	3618 DF.

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator FOSSIL FUELS INC.
3. Address of Operator SUITE 860 LB 52, 2121 SAN JACINTO STREET, DALLAS, TX.75201	4. Well Location Unit Letter <u>I</u> : <u>1980'</u> Feet From The <u>SOUTH</u> Line and <u>660'</u> Feet From The <u>EAST</u> Line Section <u>30</u> Township <u>18S</u> Range <u>39E</u> NMPM LEA County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3618 DF.	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: Deepen well in San Andres <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in equipment and rig up.
2. Pull rods, pump and tubing.
3. Pick up 4 3/4" bit with drill collars and go in hole.
4. Clean out to 4463' and drill to 4700'±.
5. If deemed necessary for a good completion run a flush joint liner cement and perforate over pay interval in the San Andres formation and complete as an oil well.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Joel Janica TITLE Agent DATE 11/17/98

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

ORIGINAL STATE OF NEW MEXICO  
DEPARTMENT OF ENERGY, MINERALS AND NATURAL RESOURCES

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

3/10