

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-20086
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1258-1
7. Lease Name or Unit Agreement Name NEW MEXICO "AE" STATE
8. Well No. 5
9. Pool name or Wildcat VACUUM ABO REEF
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3991' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Texaco Exploration and Production Inc.
3. Address of Operator P. O. Box 730 Hobbs, NM 88240	4. Well Location Unit Letter <u>K</u> : <u>1980</u> Feet From The <u>SOUTH</u> Line and <u>1980</u> Feet From The <u>WEST</u> Line Section <u>12</u> Township <u>18-S</u> Range <u>34-E</u> NMPM LEA
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3991' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1). Notify NMOCD before plugging.
- 2). MIRU pulling unit. Install BOP.
- 3). By wireline, set CIBP at 8400'. Cap w/35' (1 sx) of class "C" cmt (above pay).
- 4). Run freepoint on 2 7/8" csg.
- 5). Circulate hole w/salt gel mud (10# brine with 25# of gel per Bbl).
- 6). Set CIBP at 6100'. Cap w/35' of class "C" cmt (top of Glorieta).

(CONTINUED ON OTHER SIDE)

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Monte C. Duncan TITLE ENGINEER'S ASSISTANT DATE 10/30/92
TYPE OR PRINT NAME MONTE C. DUNCAN TELEPHONE NO. 393-7191

(This space for ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT SUPERVISOR)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

NOV 04 '92

- 7). Set CIBP at 5070'. Cap w/35' of class "C" cmt (top of San Andres).
- 8). Cut and pull csg. Circulate hole with salt gel mud.
- 9). Spot 100' plug (27 sx class "C") above cut pipe.
- 10). Spot 100' plug (27 sx class "C") across 8 5/8" shoe from 3205'-3305'.
- 11). Spot 100' plug (27 sx class "C") below salt section from 2900'-3000'.
- 12). Spot 100' plug (27 sx class "C") above salt section from 1730'-1830'.
- 13). Spot 100' plug (27 sx class "C") across 11 3/4" shoe from 280'-380'.
- 14). Spot 10 sx plug at surface.
- 15). Cut off wellhead. Install dry hole marker. Clean location.

RECEIVED

NOV 03 1992

OCD HOBBS OFFICE