

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.  
**B-1258-1**

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR NOTICES ON WELLS OR TO REPORT ON WELLS LOCATED IN A DIFFERENT RESERVOIR.  
USE APPROPRIATE FORM FOR NOTICES ON WELLS OR TO REPORT ON WELLS LOCATED IN A DIFFERENT RESERVOIR.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name -
2. Name of Operator <b>TEXACO Inc.</b>	8. Form or Lease Name <b>New Mexico 'AE' State</b>
3. Address of Operator <b>P. O. Box 728 - Hobbs, New Mexico 88240</b>	9. Well No. <b>15</b>
4. Location of Well UNIT LETTER <b>G</b> <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>11</b> TOWNSHIP <b>18-S</b> RANGE <b>34-E</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>Vacuum Abo Reef</b>
11. Elevation (Show whether DF, RT, GR, etc.) <b>3995' (GL)</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Rig up. Pull production equipment. Install BOP.
- Clean out well to PBTD 8800'.
- Perforated 2-7/8" OD csg w/2 JSPF @ 8543', 8545', 8548', 8558', 8570', 8573', 8580', 8613', 8650', 8654', 8664' & 8666'.
- Ran 2-1/16" OD tbg & acidize. Spot 300 gals 20% LST NE Acid across perforations 8529-8666'. Pull 2-1/16" tbg.
- Acidized 2-7/8" OD csg perforations 8529-8666' w/12,000 gals 20% LST NE Acid in 3 stages as follows:  
2000 gals followed by 250# Rock Salt  
5000 gals followed by 500# Rock Salt  
5000 gals.
- Swab well. Ran gas lift valves. Test and place well on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Asst. Dist. Supt. DATE 4-9-76  
Jerry Sexton  
Dist. 1, Supv.  
 APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
 CONDITIONS OF APPROVAL, IF ANY: