

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.O.S. | |
| LAND OFFICE | |
| OPERATOR | |

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
B-1031

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT - "A" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|---|
| 1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- | 7. Unit Agreement Name Central Vacuum Unit |
| 2. Name of Operator Texaco Inc. | 8. Farm or Lease Name Central Vacuum Unit |
| 3. Address of Operator P.O. Box 728, Hobbs, New Mexico 88240 | 9. Well No. 109 |
| 4. Location of Well UNIT LETTER I 2310 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 18-S RANGE 35-E NMPM. | 10. Field and Pool, or Wildcat Vacuum Grayburg San Andres |
| 15. Elevation (Show whether DF, RT, GR, etc.) 3967' (GR) | 12. County Lea |

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

| | |
|--|--|
| NOTICE OF INTENTION TO: | SUBSEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
| OTHER <input type="checkbox"/> | OTHER Repair Water Flow <input checked="" type="checkbox"/> |
| PLUG AND ABANDON <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| CHANGE PLANS <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Pull rods & pump. Install BOP. Pull tubing.
2. Set RBP @ 3920' & dump sand on plug.
3. Perforate 3 1/2" Csg. w/2-JSPF @ 1565'.
4. Cement perfs. @ 1565' w/315 sx. Class 'H' Cement containing 2% CaCl. Cement Circulated. Squeeze w/addl. 85 sx. Class 'H' Cement containing 2% CaCl. WOC. DOC.
5. Tested Csg. to 500# for 30 minutes, 10:00-10:30 AM, 7-15-82. Tested OK.
6. Install pumping equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. Dist. Mgr. DATE 8-16-82

APPROVED BY *[Signature]* TITLE DATE 8-17-1982
CONDITIONS OF APPROVAL, IF ANY: