

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-20310
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1258-1
7. Lease Name or Unit Agreement Name NEW MEXICO "AE" STATE
8. Well No. 13
9. Pool name or Wildcat VACUUM ABO REEF
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4007' DF

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Texaco Exploration and Production Inc.
3. Address of Operator P. O. Box 730 Hobbs, NM 88240	4. Well Location Unit Letter A : 990 Feet From The NORTH Line and 660 Feet From The EAST Line Section 11 Township 18-S Range 34-E NMPM LEA
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4007' DF	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1). Notify NMOCDD before plugging.
- 2). MIRU pulling unit. Install BOP.
- 3). By wireline, set CIBP at 8100'. Cap w/35' (1 sx of class "C" cmt (above pay)).
- 4). Run freepoint on 2 7/8" csg.
- 5). Circulate hole w/salt gel mud (10# brine with 25# of gel per Bbl).
- 6). Set CIBP at 5900'. Cap w/35' of class "C" cmt (top of Glorieta).

(CONTINUED ON BACK)

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Monte C. Duncan

TITLE

ENGINEER'S ASSISTANT

DATE 10/30/92

TYPE OR PRINT NAME

MONTE C. DUNCAN

TELEPHONE NO. 393-7191

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY

DISTRICT I SUPERVISOR

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NOV 04 '92

- 7). Set CIBP at 4870'. Cap w/35' of class "C" cmt (top of San Andres).
- 8). Cut and pull csg. Circulate hole with salt gel mud.
- 9). Spot 100' plug (27 sx class "C") above cut pipe.
- 10). Spot 100' plug (27 sx class "C") across 8 5/8" shoe from 3210'-3310'.
- 11). Spot 100' plug (27 sx class "C") below salt section from 2920'-3020'.
- 12). Spot 100' plug (27 sx class "C") above salt section from 1695'-1795'.
- 13). Spot 100' plug (27 sx class "C") across 11 3/4" shoe from 300'-400'.
- 14). Spot 10 sx plug at surface.
- 15). Cut off wellhead. Install dry hole marker. Clean location.

RECEIVED

NOV 03 1992

OCD HOBBS OFFICE