

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-065710

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Dry Hole	7. UNIT AGREEMENT NAME PLAINS UNIT Federal
2. NAME OF OPERATOR Pan American Petroleum Corporation	8. FARM OR LEASE NAME
3. ADDRESS OF OPERATOR Box 67, Hobbs, New Mexico 88240	9. WELL NO. 5
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface	10. FIELD AND POOL, OR WILDCAT WILDCAT WOLF CAMP
14. PERMIT NO. 1650' FSL * 1980' FEL Sec. 28 (Unit 1, NW 1/4 SE 1/4)	11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA 28-19-32 NMPM
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3583' RDB	12. COUNTY OR PARISH LEA
	13. STATE N.M.

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

No further recompletion or workover possibilities exist. Propose to P & A as follows:

1. Shoot and pull 5 1/2" casing at free point, Appx. 8800'.
2. Shoot and pull 8 5/8" casing at free point, Appx. 3500'.
3. Spot cement plugs as follows:
15 sx. from PBD 11,290' to 11,200'; 15 sx. 10,650' - 10,750' to cover perfs.
10,719-39'; 25 sx. in and out of 5 1/2" casing stub @ appx. 8800'; 25 sx. 7350-7450'; 25 sx in and out of 8 5/8" casing shoe at 4563'; spot
4. Spot appx. 6 sx Cal Seal at appx 2915'. WOC 1 hour. Top of plug as directed by USGS.
5. Spot 75 sx. cement on top of Cal Seal plug.
6. Set CIEP in bottom of 10 3/4" casing and cap with 10 sx cement.
7. Spot 10 sx cement plug at surface and erect P & A marker.

Make final clean-up and restore ground to contour.

Pursuant to telephone approval, Jones Brown to Jones. 11-15-67

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Area Superintendent

DATE 11/28/67

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DEC 5 1967

DATE

A. R. BROWN
DISTRICT ENGINEER

*See instructions on Reverse Side

4 USGS - H
1 NSW
1 Susp
1-RRY
1-MOBIL Midland