

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 0750-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

USA Trigg Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lusk-Strawn

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 8, T19S, R32E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

TENNECO OIL COMPANY

3. ADDRESS OF OPERATOR

1860 Lincoln Street - Suite 1200 - Denver, Colorado 80203

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*

See also space 17 below.)  
At surface

1650 FSL, 1650 FWL  
Sec. 8, T19S, R32E  
Lea County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3623 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐  
☐  
☐  
☐

PULL OR ALTER CASING

☐  
☐  
☒  
☐

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐  
☐  
☐

REPAIRING WELL

☐  
☐  
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Notify USGS, Hobbs, New Mexico office prior to setting first bridge plug. All mud between plugs to be equivalent to 25 sx. gel/100 bbls. water.

1. Install BOP, pull both strings of tubing with packers.
2. Set CIBP @ 12,000'  $\pm$ . Cap with 35' cement. Set CIBP @ 10,500'  $\pm$  and cap with 35' cement.
3. Work 5 1/2" casing, determine free point. If above 8500, set CIBP @ 8500' and cap with 35' cement. Shoot 5 1/2" casing and lay down. Spot 100' cement plug at 5 1/2 stub using tubing.
4. Spot 100' plugs through tubing as follows: 7050 - 6950 (Bone Springs); 5450 - 5350 (Delaware) and 4050 - 3950 (8 5/8 shoe).
5. Shoot off 8 5/8 and lay down. Spot 100' cement plug at 8 5/8 stub, 100' plug at 900 - 1000' (Anhydrite) and 100' plug at 800 - 900 at shoe of surface casing.
6. Spot 20 sx plug at surface and install dry hole marker.

APPROVED SUBJECT TO POSSIBLE FUTURE  
REQUIREMENT THAT PAD AND/OR ROAD  
BE RIPPED AND RELEVELLED

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Sr. Production Clerk

DATE August 9, 1974

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED  
BRACLEY  
AUG 8 1974

ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side