

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2068
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1733	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Texaco Inc.		New Mexico 'L' State
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		8-1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>G</u> <u>1900</u> FEET FROM THE <u>North</u> LINE AND <u>1880</u> FEET FROM		Vacuum Glorieta
THE <u>East</u> LINE, SECTION <u>1</u> TOWNSHIP <u>18-S</u> RANGE <u>34-E</u> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3908' (DF)		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP.
2. Set cement retainer @ 5800'. Squeeze perfs. 6082'-6156' w/25 sx. class 'H' cement.
3. Spot 5 sx. cement on top of cement retainer.
4. Spot 100' (6 sx.) cement plug from 4190'-4090'.
5. Cut 2 7/8" csq. @ 4070' & pull. Spot 100' (35 sx.) cement plug from 3420'-3320'.
6. Spot 100' (35 sx.) cement plug from 2640'-2540'.
7. Spot 100' (35 sx.) cement plug from 1660'-1560'.
8. Perforate 8 5/8" csq. w/2-JS @ 1500'. Set cement retainer @ 1450'. Cement to surface perf w/550 sx. class 'H' cement.
9. Spot 100' (35 sx.) cement plug from 300'-200'.
10. Spot 30' (10 sx.) cement plug @ surface.
11. Install dry hole marker & clean up location. Well P & A.

THIS COPY OF THE REPORT ON WELL P & A IS TO BE FILED IN THE C-103 FILE IN THE OIL CONSERVATION DIVISION OF THE NEW MEXICO DEPARTMENT OF ENERGY AND MINERALS.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Assistant District Superintendent 2/3/81</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>
CONDITIONS OF APPROVAL, IF ANY:	DATE <u>FEB 3 1981</u>