

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E-1774-2

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator PENNZOIL COMPANY	8. Farm or Lease Name ROCK ISLAND STATE <i>By 2</i>
3. Address of Operator P.O. DRAWER 1828, MIDLAND, TX 79702-1828	9. Well No. 2
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>NORTH</u> LINE AND <u>660</u> FEET FROM THE <u>WEST</u> LINE, SECTION <u>3</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat VACUUM LOWER WC N.
15. Elevation (Show whether DF, RT, GR, etc.) 4074 GR	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 10,090' and dump 35' cmt on top - this will cover all Wolfcamp perforations.
2. Circulate hole with 10# brine water containing salt gel.
3. Spot 100' cmt plug (Class H) from 8063' to 7963' to cover the ABO.
4. Spot 100' cmt plug (Class H) from 6087' to 5987' to cover the GLORIETA.
5. Shoot and pull 4100' of 5 1/2" casing.
6. Spot 100' cmt plug (Class C) from 4150 to 4050'. This plug will cover the 5 1/2" casing stub and the 8 5/8" casing shoe (50' in and 50' out).
Tag this plug before continuing.
7. Spot 100' cmt plug (Class C) from 2850' to 2750' to cover the base of the salt.
8. Shoot and pull 1900' of 8 5/8" casing.

(Please turn to the back side)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jerry Sexton</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>2-13-85</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>FEB 21 1985</u>
CONDITIONS OF APPROVAL, IF ANY:		

9. Spot 200' cmt plug (Class C) from 1950' to 1750'. This plug will cover the 8 5/8" csg stub and the top of the salt section. Tag this plug before continuing.
10. Spot 100' cmt plug (Class C) from 405' to 305' to cover the 13 3/8" csg shoe (50' in and 50' out).
11. Spot 10 sx Class C at surface and install marker.

ANTICIPATED STARTING DATE 3-15-85.

RECEIVED

FEB 20 1985

C.C.D.
HOLDS OFFICE