

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLI  
(Other instructions  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

New Mexico 04591

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Mobil Oil Corporation

3. ADDRESS OF OPERATOR

Three Greenway Plaza East, Suite 800, Houston, TX 77046

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

990' FSL &amp; 660' FEL Unit P, Section 24, T-18-S, R-33-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3945 GR

12. COUNTY OR PARISH

Lea

13. STATE

N. M.

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON\*

CHANGE PLANS

X

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Run 5½" cement retainer on tubing to 4350'± and squeeze Queen perms (4401-4449') with 50 sx Class "H" neat cement.
2. Pull out of retainer and spot 5 sx. neat cement on top of retainer.
3. Load hole with 9.5#/gal. fluid.
4. Run "free-point" log and pull all available 5½" casing.
5. Run tubing to 3070'± and spot 25 sx Class "H" neat cement.
6. Pull tubing to 1750'± and spot 25 sx Class "H" neat cement.
7. Pull tubing to 50' below casing cut (est. - 600') and spot 90 sx Class "H" neat cement.
8. WOC
9. Check cement top to be no less than 335'.
10. Pull tubing and set 10 sx surface plug with Class "H" neat cement.
11. Erect monument and clear location.

NOTE: Verbal approval from U.S.G.S.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Authorized Agent

DATE 1-3-77

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

APPROVED  
AS AMENDED  
JAN 14 1977  
BERNARD MOROZ  
ACTING DISTRICT ENGINEER