

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name E. K. Queen Unit Tr. 7
9. Well No. 6
10. Field and Pool, or Wildcat E. K. Yates 7/Rivers Q.
12. County Lea

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- WIW
2. Name of Operator Mobil Oil Corporation
3. Address of Operator Three Greenway Plaza East, Suite 800, Houston, Texas 77046
4. Location of Well UNIT LETTER <u>L</u> <u>2310</u> FEET FROM THE <u>South</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>24</u> TOWNSHIP <u>18-S</u> RANGE <u>33-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3876 GR

16.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Pull tubing and packer from well.
- Run 5½" cement retainer on tubing to 4150'± and squeeze Queen perfs (4293'-4366') with 50 sx Class "H" neat cement.
- Pull out of retainer and spot 5 sx neat cement on top of retainer.
- Load hole with 9.5#/gal fluid.
- Pull tubing to 3000' and spot 25 sx Class "H" neat cement.
- WOC
- Check cement top to be no less than 2880'.
- Pull tubing to 1800'± and spot 40 sx Class "H" neat cement.
- WOC
- Check cement top to be no less than 1545'.
- Pull tubing to 425' and spot 25 sx Class "H" neat cement.
- WOC
- Check cement top to be no less than 300'.
- Pull tubing and set 10 sx. surface plug with Class "H" neat cement.
- Erect monument and clear location.

NOTE: Verbal approval from N.M.O.C.C.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Authorized Agent</u>	DATE <u>1-3-77</u>
APPROVED BY <u>Jerry Boston</u> <u>Dist. 1. Supv.</u>	TITLE <u></u>	DATE <u>JAN 7 1977</u>

RECEIVED

JAN 6 1977

OIL CONSERVATION COMM.  
HOBBS, N. M.